

◆ Clear Energy

Users press “Back” button to enter “1.Enter Setting” interface, Press “OK” button to enter main setting interface. Then Enter “2.Clear Energy ” by pressing “Up” button or “Down” button, press “OK” button and start to clear produce. “success” is displayed after settings.

◆ Clear Events

Users press “Back” button to enter “1.Enter Setting” interface, Press “OK” button to enter main setting interface.Enter “3. Clear Events” by pressing “Up” button or “Down” button. Press “OK ”button and start to clear events. “success” is displayed after settings.

◆ Set Country Code

Users press “Back” button to enter “1.Enter setting” interface, Press OK button to enter main setting interface. Enter “4.Set Country Code” by pressing “Up” button Or “Down” button, press “OK” button and enter “Input Password” Setting interface(default:0001).If it's shown"set disable" on the screen,then you can NOT choose the operating country, you should enable country setting through " 6. Enset Country " interface. If it's shown "set Country code?" on the screen, then press Confirm button to start country setting. "Success" will be shown on the screen after a successful country setting.

User can check current country code in SystemInfo>>5. Country.

Note: Country code changing will take effect after inverter reboot.

Table 6-1 country code setting

code	country	code	country	code	country
00	Germany VDE AR-N4105	12	Poland	24	Cyprus
01	CEI0-21 Internal	13	Germany BDEW	25	India
02	Australia	14	Germany VDE 0126	26	Philippines
03	Spain RD1699	15	Italy CEI0-16	27	NewZealand
04	Turkey	16	UK-G83	28	Brazil
05	Denmark	17	Greece island	29	Slovakia VSD
06	Greece Continent	18	EU EN50438	30	Slovakia SSE
07	Netherland	19	IEC EN61727	31	Slovakia ZSD
08	Belgium	20	Korea	32	CEI0-21 In Areti
09	UK-G59	21	Sweden	33	Ukraine
10	China	22	Europe General	34-49	Reserved
11	France	23	CEI0-21 External		

◆ On-Off Control

Users press "Back" button to enter "1.Enter Setting" interface,Press "OK" button to enter main setting interface.Enter "5.On-Off Control" by pressing "UP" button or "Down" button. Press "OK" button and enter On-Off Control interface,press "OK" button and enter "Input Password" Setting interface.Press "OK" button to set passwords (default:0001),increase or decrease value though pressing "Up" button or "Dwon" button,press "OK" button to next value setting."Error! Try again" will be displayed for wrong passwords.Press "back" button and rekey in the correct passwords.It will enter into "Power on&Power off" interface if the passwords is correct,then you can select "Power on" or "Power off" by pressing "Up" button or "Down" button and press "OK" button to finish the setting successfully.If you select "Power off",need to set how many days you want the inverter to power off,increase or decrease value though pressing "Up" button or "Down" button.After you set "Power off" successfully,you need to contact manufacturer to supply passwords to re-power on this inverter.

◆ Enset Country

Users press “Back” button to enter “1.Enter Setting” interface, Press “OK” button to enter main setting interface.Enter “ 6. Enset Country ” by pressing “Up” button or“Down”button, press “OK” button and enter “Input Password” Setting interface.

Press “Back” button to set passwords (default: 0001), increase or decrease value though pressing “Up” button or “Down” button, press “OK” button to next value setting. “Error! Try again” will be displayed for wrong passwords. Press “Back” button and rekey in the correct passwords. “success” will be displayed if setting successfully,

Attention: when inverter working for power generation over 24h, country setting is forbidden, it can only be set after LCD setting. Key in passwords for country setting through LCD (default: 0001), country setting can be set in 24h after keying in the correct passwords, over 24h, set through LCD again.

◆ Set Energy

Users press “Back” button to enter “1.Enter Setting” interface, Press “OK” button to enter main setting interface.Enter “ 7.Set Energy ” by pressing “ Up ” button or“Down”button, press “OK” button and enter “Input Password” Setting interface.

Press “Back” button to set passwords (default: 0001), increase or decrease value though pressing “Up” button or “Down” button, press “OK” button to next value setting. “Error! Try again” will be displayed for wrong passwords. Press “Back” button and rekey in the correct passwords. “success” will be displayed if setting successfully,

◆ Set Address

Users press “Back” button to enter “1.Enter setting” interface, Press “OK” button to enter main setting interface. Enter “8. Set Address” by pressing “Up” button or “Down” button. Press “OK” button and enter setting interface “Success” or “fail” is displayed after setting.

◆ Set Inputmode

Input mode selection : Sofar 10K~15KTL-G2 has 2 MPPT, The two MPPT can run independently, and also can be operated in parallel, According to the system design, the user can choose the mode of MPPT operation.The input mode can be setting by the LCD .

Users press “Back” button to enter “1.Enter setting” interface, Press “OK” button to enter main setting interface. Enter “ 9. Set inputmode” by pressing “Up” button or “Down” button. Press “OK” button and enter setting interface. Choose corresponded setting items by pressing “Up” button or “Down” button, then press “OK” button. “Success” or “fail” is displayed after setting.

◆ Set Language

Users press “Back” button to enter “1.Enter setting” interface, Press “OK” button to enter main setting interface. Enter “10. Set Language” by pressing “Up” button or “Down” button. Press “OK” button and enter setting interface. Choose corresponded setting items by pressing “Up” button or “Down” button, then press “OK” button. “Success” or “fail” is displayed after setting.

◆ Set StartPara

User can change the start parameter by the LCD. First the User need to copy the. TXT file which is used to change the start parameter to the SD card .

Users press Back button to enter “1.Enter setting” interface, Press OK button to enter main setting interface. Enter “11. Set StartPara” by pressing “Up” button Or “Down” button, press “OK” button and enter “Input Password” Setting interface. Press “Back” button to set passwords (default: 0001), increase or decrease value though pressing “Up” button or “Down” button, press “OK” button to next value setting. “Error!” Try again” will be displayed for wrong passwords. Press “Back” button and rekey in the correct passwords. “Success” will be displayed if setting successfully.

◆ Set SafetyVolt

User can change the Voltage protection point by the LCD. First the User need to copy the. TXT file which is used to change the Voltage protection point to the SD card .

Users press Back button to enter “1.Enter setting” interface, Press OK button to enter main setting interface. Enter “12. Set SafetyVolt” by pressing “Up” button Or “Down” button, press “OK” button and enter “Input Password” Setting interface. Press “Back” button to set passwords (default: 0001), increase or decrease value though pressing “Up” button or “Down” button, press “OK” button to next value setting. “Error!” Try again” will be displayed for wrong passwords. Press “Back” button and rekey in the correct passwords. “Success” will be displayed if setting successfully.

◆ Set SafetyFreq

User can change the Frequency protection point by the LCD. First the User need to copy the. TXT file which is used to change the Frequency protection point to the SD card .

Users press Back button to enter “1.Enter setting” interface, Press OK button to enter main setting interface. Enter “13. Set SafetyFreq” by pressing “Up” button Or “Down” button, press “OK” button and enter “Input Password” Setting interface. Press “Back” button to set passwords (default: 0001), increase or decrease value though pressing “Up” button or “Down” button, press “OK” button to next value setting. “Error!” Try again” will be displayed for wrong passwords. Press “Back” button and rekey in the correct passwords. “Success” will be displayed if setting successfully.

◆ Set Insulation

User can change the Insulation protection point by the LCD. First the User need to copy the. TXT file which is used to change the Insulation protection point to the SD card .

Users press Back button to enter “1.Enter setting” interface, Press OK button to enter main setting interface. Enter “14. Set Insulation” by pressing “Up” button Or “Down” button, press “OK” button and enter “Input Password” Setting interface. Press “Back” button to set passwords (default: 0001), increase or decrease value though pressing “Up” button or “Down” button, press “OK” button to next value setting. “Error!” Try again” will be displayed for wrong passwords. Press “Back” button and rekey in the correct passwords. “Success” will be displayed if setting successfully.

◆ Set RefluxP

Users press "Back" button to enter "1.Enter Setting" interface,Press "OK" button to enter main setting interface.Enter "18.Set RefluxP" by pressing "Up" button or "Down" button, press "OK" button and enter "Input Password" Setting interface.Press "OK" button to set passwords (default:0001),increase or decrease value though pressing "Up" button or "Dwon" button,press "OK" button to next value setting."Error! Try again" will be displayed for wrong passwords.Press "back" button and rekey in the correct passwords.Then select "Reflux Enable" or "Reflux Disable" by pressing "Up" and "Down" button."success" will be displayed if setting successfully.

◆ DRMS0 Control(only Australia)


Enable the function to refer "4.4 Connecting communication cables"connection DRED, Users press Back button to enter "1.Enter setting"interface,Press OK button to enter main setting interface.Enter"18.DRMS0 Control"by pressing "Down"button,press"OK" button and enter “ Input Password ” Setting interface . Press “Back” button to set passwords (default: 0001), increase or decrease value though pressing “Up” button or “Down” button, press “OK” button to next value setting. “Error!” Try again” will be displayed for wrong passwords. Press “Back” button and rekey in the correct passwords. If the password is correct, enter the settings "1.enable DRMS0 or press down to enter "2.disable DRMS0", and finally press the OK button to set it successfully.

◆ Autotest Fast

Step 1: During the normal operation of our SOLAR inverters, press “back” button (the leftmost button) to enter the main menu interface.

Step 2:Press “Confirm” button (the rightmost button) to enter the “Enter Setting” menu interface.


Step 3:Press “Down” button several times until “Autotest Fast” is shown on the screen.





Step 4:Press “Confirm” button to start Auto Test:



Step 5:Then the Auto Test will start automatically, Press “down” to see the test results






◆ Autotest STD

Step 1:during the normal operation of our SOLAR inverters,press “back”button (the leftmost button) to enter the main menu interface

Step 2:Press “Confirm”button (the rightmost button)to enter the “setting”menu interface.


Step 3:Press “Down”button several times until “Autotest slow”is shown on the screen





Step 4:Press “Confirm” button to start Auto Test:



Step 5:Then the Auto Test will start automatically, Press “down” to see the test results






(B) “Event List” Interface as below:

Event List is used to display the real-time event records, including the total number of events and each specific ID No. and happening time. User can enter Event List interface through main interface to check details of real-time event records, Event will be listed by the happening time, and recent events will be listed in the front. Please refer to below picture:

Users press “Back” button and “Down” button in standard interface, then enter into 2.Event List” interface.



(C) “SystemInfo” Interface as below:

3.SystemInfo	
	1.Inverter Type
	2.Serial Number
	3.SoftVersion
	4.HardVersion
	5.Country
	6.Input Mode
	7.Safety Paras
	8.Power factor
	9.MPPT Scan

◆ Inverter Type

Users press “Back” button and “Up” button or “Down” button enter “3. SystemInfo” interface, Press “OK” button to enter enter into system information checking interface,then press “Up” button or “Down” button enter into “1. Inverter Type”,then press “OK” button , the Inverter Type will be displayed.

◆ Serial Number

Users press “Back” button and “Up” button or “Down” button to enter “3. SystemInfo” interface, Press “OK” button to enter enter into system information checking interface,then press “Up” button or “Down” button enter into “2. Serial Number”,then press “OK” button ,the serial number will be displayed.

◆ SoftVersion

Users press “Back” button and “Up” button or “Down” button to enter “3. SystemInfo” interface, then Press “OK” button to enter enter into system information checking interface,then press “Up” button or “Down” button enter into “3. SoftVersion”,then press “OK” button , the SoftVersion will be displayed.

◆ HardVersion

Users press “Back” button and “Up” button or “Down” button to enter “3. SystemInfo” interface, then Press “OK” button to enter enter into system information checking interface,then press “Up” button or “Down” button enter into “4. HardVersion”,then press “OK” button , the HardVersion will be displayed.

◆ Country

Users press “Back” button and “Up” button or “Down” button to enter “3. SystemInfo” interface, then Press “OK” button to enter enter into system information checking interface,then press “Up” button or “Down” button enter into “5. Country”,then press “OK” button , the Country will be displayed.

◆ Input Mode

Users press “Back” button and “Up” button or “Down” button to enter “3. SystemInfo” interface, then Press “OK” button to enter enter into system information checking interface,then press “Up” button or “Down” button enter into “6. Input Mode”,then press “OK” button , the Input Mode will be displayed.

◆ Power factor

Users press “Back” button and “Up” button or “Down” button to enter “3. SystemInfo” interface, then Press “OK” button to enter enter into system information checking interface,then press “Up” button or “Down” button enter into “ 7. Power factor ”,then press “OK” button , the Power factor will be displayed.

(D) System Time

Press the “Back” button and “Up” button or “Down” key in the standard user interface to enter into “4.System Time”,then press “OK ” button to display the current system time.

(E) Software Update

Press the “Back” button and “Up” button or “Down” button in the standard user interface to enter into “5. Software Update”,then press “OK” button to enter into the“input password” interface,now press the “OK” button to input the password(initial passwords is 0715),Press the“Up” and “Down” button to change the value,then press “OK” button to confirm the current value of input and enter the next set of value .when set over, if the password is wrong, the LCD will display “Error! Try again”,at this time ,you should re-enter your password.If the password is correct, then begin the update process.

User can check the current software version in SystemInfo>>3. SoftVersion.

online update program steps are as follows:

- Step 1 First, open SOFAR 10K~15KTL-G2 waterproof cover.
- Step 2 After open waterproof cover, Press SD card (the SD card as shown in Figure 4-5), Then the SD card will automatically pop up.
- Step 3 The SD card reader must be ready by the users, so that SD card so easy to establish the connection with the computer.
- Step 4 SOFAR SOLAR will send the Software code to the user who needs to update. After user receive the file, please decompressing file and cover the original file in SD card.
- Step 5 Insert the SD card into the SD card slot, there will be a faint clicking sound typically, indicating that has stuck.
- Step 6 then enter into the online upgrade to the main menu “5. Software Update” in the LCD display program. The method to enter the menu can refer to operation interface of LCD.
- Step 7 Input the password, if password is correct, and then begin the update process, the original password is 0715.
- Step 8 System update main DSP、slave DSP、 and ARM in turns. If main DSP update success ,the LCD will display “Update DSP1 OK”, otherwise display “Update DSP1 Fail”; If slave DSP update success ,the LCD will display “Update DSP2 OK”, otherwise display “Update DSP2 Fail” .
- Step 9 If Fail , please turn off the DC breaker, wait for the LCD screen extinguish, then turn on the DC breaker again,then Continue to update from step 6.
- Step 10 After the update is completed, turn off the DC breaker, wait for the LCD screen extinguish, then install waterproof cover, and turn on the DC breaker and AC breaker again, the inverter will enters the running state.
User can check the current software version in SystemInfo>>3. SoftVersion.



Trouble shooting and maintenance

7.1 Trouble shooting

This section contains information and procedures for solving possible problems with the sof ar 10K~15KTL-G2 inverter.

- ☉ **In case of problem with inverter, check the following tips.**
- Check the warning fault messages or Fault codes on the inverter information panel. Record it before doing anything further.
- If inverter does not display any Fault, please check the following lists.
 - Is the inverter located in a clean, dry, adequately ventilated place?
 - Is the DC switch turned ON?
 - Are the cables adequately sized and short enough?
 - Are the input and output connections and wiring in good condition?
 - Are the configuration settings correct for the particular installation?
 - Are the display panel and the communications cable properly connected and undamaged?

Follow the steps below to view recorded problems:

Press “ESC” to enter the main menu in the normal interface. In the interface screen select “Event List”, then press “OK” to enter events.

☉ EventList information

Table 7-1 Eventlist

EventList NO.	EventList Name	EventList description	solution
ID01	GridOVP	The power grid voltage is too high	<ul style="list-style-type: none">• If the alarm occurs occasionally, the possible cause is that the electric grid is abnormal occasionally. SOFAR inverter automatically returns to normal operating status when the electric grid’s back to normal.• If the alarm occurs frequently, check whether the grid voltage/frequency is within the acceptable range. If no, contact SOFAR technical support. If yes, check the AC circuit breaker and AC wiring of the SOFAR inverter.• If the grid voltage/frequency is within the acceptable range and AC wiring is correct, while the alarm occurs repeatedly, contact SOFAR technical support to change the grid over-voltage, under-voltage, over-frequency, under-frequency protection points after obtaining approval from the local electrical grid operator.
ID02	GridUVP	The power grid voltage is too low	
ID03	GridOFP	The power grid frequency is too high	
ID04	GridUFP	The power grid frequency is too low	

ID05	PVUVP	The input voltage is too low	Check whether too few PV modules are series connected in a PV string, thus the voltage(Vmp) of the PV string is lower than the minimum operating voltage of SOFAR inverter. If yes, adjust the number of series connected PV modules to increase the voltage of the PV string to fit the input voltage range of SOFAR inverter. SOFAR inverter automatically returns to normal operating status after correct adjustments.
ID09	PvOVP	The input voltage is too high	Check whether too many PV modules are series connected in a PV string, thus the voltage(Voc) of the PV string is higher than the maximum input voltage of SOFAR inverter. If yes, adjust the number of series connected PV modules to decrease the voltage of the PV string to fit the input voltage range of SOFAR inverter. SOFAR inverter automatically returns to normal operating status after correct adjustments.
ID10	IpvUnbalance	Input current is not balanced	Check the input mode(parallel mode/ independent mode) setting of SOFAR inverter according to Section 4.5 of this user manual.
ID11	PvConfigSetWrong	Incorrect input mode	
ID12	GFCIFault	GFCI Fault	<ul style="list-style-type: none">• If the fault occurs occasionally, the possible cause is that the external circuits are abnormal occasionally. SOFAR inverter automatically returns to normal operating status after the fault is rectified.• If the fault occurs frequently and lasts a long time, check whether the insulation resistance between the PV array and earth(ground) is too low, then check the insulation conditions of PV cables.
ID14	HwBoostOCP	Ihe input current is too high,and has happen hardware protection	Check whether the input current is higher than the maximum input current of SOFAR inverters, then check the input wiring, if both are correct, please contact SOFAR technical support.
ID15	HwAcOCP	The grid current is too high,and has happen hardware protection	ID15-ID24 are internal faults of SOFAR inverter, turn OFF the “DC switch”, wait for 5 minutes, then turn ON the “DC switch”. Check whether the fault is rectified. If no, please contact SOFAR technical support.
ID16	AcRmsOCP	The grid current is too high	
ID17	HwADFaultIGrid	The grid current sampling error	
ID18	HwADFaultDCI	The DCI sampling error	
ID19	HwADFaultVGrid	The grid voltage sampling error	
ID20	GFCIDeviceFault	The GFCI sampling error	
ID21	MChip_Fault	The master chip fault	
ID22	HwAuxPowerFault	The auxiliary voltage error	
ID23	BusVoltZeroFault	The bus voltage sampling error	
ID24	IacRmsUnbalance	The Output current is not balanced	

ID25	BusUVP	The bus voltage Is too low	If the PV array configuration is correct (no ID5 fault), the possible cause is that the solar irradiance is too low. SOFAR inverter automatically returns to normal operating status after the solar irradiance returns to normal level.
ID26	BusOVP	The bus voltage Is too high	ID26-ID27 are internal faults of SOFAR inverter, turn OFF the “DC switch”, wait for 5 minutes, then turn ON the “DC switch”. Check whether the fault is rectified. If no, please contact SOFAR technical support.
ID27	VbusUnbalance	The bus voltage is not balanced	
ID28	DciOCP	The Dci is too high	
ID29	SwOCPIstant	The grid current is too high	<ul style="list-style-type: none">• Check the input mode(parallel mode/ independent mode) setting of SOFAR inverter according to Section 4.5 of this user manual.• If the input mode is correct, turn OFF the “DC switch”, wait for 5 minutes, then turn ON the “DC switch”. Check whether the fault is rectified. If no, please contact SOFAR technical support.
ID30	SwBOCPIstant	Ihe input current is too high	Internal faults of SOFAR inverter, turn OFF the “DC switch”, wait for 5 minutes, then turn ON the “DC switch”. Check whether the fault is rectified. If no, please contact SOFAR technical support.
ID49	ConsistentFault_VGrid	The grid voltage sampling value between the master DSP and slave DSP is not consistent	ID49-ID55 are internal faults of SOFAR inverter, turn OFF the “DC switch”, wait for 5 minutes, then turn ON the “DC switch”. Check whether the fault is rectified. If no, please contact SOFAR technical support.
ID50	ConsistentFault_FGrid	The grid frequency sampling value between the master DSP and slave DSP is not consistent	
ID51	ConsistentFault_DCI	The DCI sampling value between the master DSP and slave DSP is not consistent	
ID52	ConsistentFault_GFCI	The GFCI sampling value between the master DSP and slave DSP is not consistent	
ID53	SpiCommLose	The spi communication between the master DSP and slave DSP is fault	
ID54	SciCommLose	The Sci communication between the control board communication board is fault	
ID55	RelayTestFail	The relays fault	
ID56	PvIsoFault	The insulation resistance is too low	Check the insulation resistance between the PV array and earth(ground), if a short circuit occurs, rectify the fault.
ID58	OverTempFault	The inverter temp is too high	<ul style="list-style-type: none">• Ensure the installation position and installation method meet the requirements of Section 3.4 of this user manual.• Check whether the ambient temperature of the installation position exceeds the upper limit. If yes, improve ventilation to decrease the temperature.• Check whether the ID90~ID92 fault (fan fault) exist, if yes, please replace the corresponding fan.
ID59	OverTempFault_Env	The environment temp is too high	
ID60	Grounding abnormal	Grounding abnormal	
ID60	Grounding abnormal	Grounding abnormal	Check whether the ground is solid

ID65	UnrecoverHwAcOCP	The grid current is too high,and has cause unrecoverable hardware fault	ID65-ID70 are internal faults of SOFAR inverter, turn OFF the “DC switch”, wait for 5 minutes, then turn ON the “DC switch”. Check whether the fault is rectified. If no, please contact SOFAR technical support.
ID66	UnrecoverBusOVP	The bus voltage is too high,and has cause unrecoverable fault	
ID67	UnrecoverIacRmsUnbalance	The grid current is unbalance,and has cause unrecoverable fault	
ID68	UnrecoverIpvUnbalance	The input current is unbalance,and has cause unrecoverable fault	
ID69	UnrecoverVbusUnbalance	The bus voltage Is unbalance,and has cause unrecoverable fault	
ID70	UnrecoverOCPIstant	The grid current is too high,and has cause unrecoverable fault	
ID71	UnrecoverPvConfigSetWrong	Incorrect input mode	Check the input mode(parallel mode/ independent mode) setting of SOFAR inverter according to Section 4.5 of this user manual.
ID74	UnrecoverIPVInstant	The input current is too high,and has happen unrecoverable fault	ID74-ID77 are internal faults of SOFAR inverter, turn OFF the “DC switch”, wait for 5 minutes, then turn ON the “DC switch”. Check whether the fault is rectified. If no, please contact SOFAR technical support.
ID75	UnrecoverWRITEEEPROM	The EEPROM is unrecoverable	
ID76	UnrecoverREADEEPROM	The EEPROM is unrecoverable	
ID77	UnrecoverRelayFail	Relay has happen permanent fault	
ID81	OverTempDerating	the inverter has derated because of the temperature is too high	<ul style="list-style-type: none">• Ensure the installation position and installation method meet the requirements of Section 3.4 of this user manual.• Check whether the ambient temperature of the installation position exceeds the upper limit. If yes, improve ventilation to decrease the temperature.• Check whether the ID90~ID92 fault (fan fault) exist, if yes, please replace the corresponding fan.
ID82	OverFreqDerating	the inverter has derated because of the grid frequency too hig	SOFAR inverter automatically reduce the output power when the frequency of electrical grid is too high.
ID83	RemoteDerating	The inverter has derated by the Remote control	SOFAR inverter records ID83 in case of remote power derating operation. Check the wiring of remote input and output control signal port on the communication board according to Section 4.4 of this user manual.
ID84	RemoteOff	The inverter has shut down because by the Remote control	SOFAR inverter records ID84 in case of remote shutdown operation. Check the wiring of remote input and output control signal port on the communication board according to Section 4.4 of this user manual.

ID91	Fan1 alarm	Fan 1 fault	Check the external fan with blue cable, if it is fault , contact Sofar to replace it.
Id92	Fan2 alarm	Fan 2 fault	Check the external fan with red cable, if it is fault , contact Sofar to replace it.
ID94	Software version is not consistent	The Software between the control board and the communication board is not consistent	Contact SOFAR technical support to upgrade software.
ID95	Communication board EEPROM fault	The Communication board EEPROM is fault	ID95~ID96 are internal faults of SOFAR inverter, turn OFF the “DC switch”, wait for 5 minutes, then turn ON the “DC switch”. Check whether the fault is rectified. If no, please contact SOFAR technical support.
ID96	RTC clock chip anomaly	RTC clock chip is fault	
ID97	Invalid Country	The Country is InValid	Check the country setting according to Section 4.4 of this user manual.
ID98	SD fault	The SD card is fault	Please replace the SD card.
ID99- ID100	Reserved		Reserved

7.2 Maintenance

Inverters generally do not need any daily or routine maintenance.

☉ **Inverter cleaning**

Please use hand blower, soft dry cloth or brush to clean inverters. Water, corrosive chemical substances or intense cleaning agent should not be used for cleaning the cooling fan or inverter. Switch off AC and DC power supply to inverter before undertaking any cleaning activity.

8 Decommissioning

8.1 Decommissioning steps

- Switch off the AC grid
- Switch Off the DC switch
- Wait for 5 minutes
- Release the DC connectors
- Release the AC terminals using screw drivers.

8.2 Package

If possible, please pack the inverter in the original packaging.

8.3 Storage

Store the inverter in a dry place where ambient temperature is between -25 and - +70 °C.

8.4 Disposal

At the end of its life, dispose inverters and packing materials at locations that can handle and or recycle electric equipment safely.

9) Technical data

9.1 Input parameters (DC)

Technical Data	SOFAR 10000TL-G2	SOFAR 12000TL-G2	SOFAR 15000TL-G2
Max. DC Input power	18000W	18000W	18000W
Max. Input voltage	1000V		
Start-up voltage	180V		
MPPT voltage range	160V-960V		
Rated voltage	600V		
Full load voltage range	350V-850V	500V-850V	500V-850V
Max input current	21A/11A		
Max. PV Short current Isc	30A/15A		
MPPT No. /String No.	2/2+1		

9.2 Output parameters (DC)

Technical Data	SOFAR 10000TL-G2	SOFAR 12000TL-G2	SOFAR 15000TL-G2
Rated output power	10000W	12000W	15000W
Max apparent power	11000VA	13200VA	16500VA
Max output current	3*16.5A	3*20A	3*24A
Output voltage range	230/400V; 184-275V		
AC Grid frequency	50/60HZ		
Power factor range	0.8leading- 0.8laging		
THDi@100% load	<3%		
Grid	3/N/PE		

9.3 Effiecný

Technical Data	SOFAR 10000TL-G2	SOFAR 12000TL-G2	SOFAR 15000TL-G2
Max efficiency	98.3%	98.3%	98.3%
European efficiency	98%	98%	98%
MPPT efficiency	99.9%	99.9%	99.9%

9.4 Protection and Characteristic

Technical Data	SOFAR 10000TL-G2	SOFAR 12000TL-G2	SOFAR 15000TL-G2
Input reverse polarity	yes		
Output over current	yes		
Output over voltage	yes		
Anti-islanding	yes		
RCMU	yes		
PV Insulation	yes		
Surge protection level	III		
Common parameters			
Dimension(W*H*D)[mm]	540*452*202		
Weight [kg]	23.5Kg	23.5Kg	25Kg
Operation temperature range	-25~60°C		
Noise	≤45dB(A)		
Altitude	2000m		
Night consume	<0.5W		
Topology	Transformer-less		
Cooling	Fan		
Ingress protection	IP65		
Humidity	0...100%		
DC Connector	Mc4		
AC Connector	Screw		
Display	4.7 inch LCD		
Communication	RS485(Default)WIFI/GPRS/Ethernet(optional)		
Certificate	IEC62109-1,IEC62109-2,NB-T 32004		
Maximum Inverter backfeed current to array(dc μA)	<800uA		
Inrush current output inrush current and duration	0.8A/2us		
Maximum output fault current	200A Peak		
Maximum output over current protection	65A		
Protective class	Class I		
Over voltage category	PV: OVC II, AC mains: OVC III		
Environment pollution degree	Outside housing: Degree 3 Inside housing: Degree 2		
Warranty	3/5/7/10 years		

10 Quality Assurance

10.1. Standard warranty period

- The standard warranty period of inverter is 60 months (5 years).There are two calculation methods for the warranty period:
1. Purchase invoice provided by the customer: the first flight provides a standard warranty period of 60 months (5 years) from the invoice date;
 2. The customer fails to provide the invoice: from the production date (according to the SN number of the machine), Our company provides a warranty period of 63 months (5.25 years).
 3. Other pv components GPRS, WIFI, warranty period of 5 years;Lightning protection is guaranteed for 3 years. Damage caused by lightning is not covered by the warranty.
 4. In case of any special warranty agreement, the purchase agreement shall prevail.

10.2. Extended warranty period

- Within 12 months of the purchase of the inverter (based on the purchase invoice) or within 24 months of the production of the inverter(SN number of machine, based on the first date of arrival),Customers can apply to buy extended warranty products from the company's sales team by providing the product serial number, Our company may refuse to do not conform to the time limit extended warranty purchase application.Customers can buy an extended warranty of 5, 10, 15 years.
- If the customer wants to apply for the extended warranty service, please contact the sales team of our company. to purchase the products that are beyond the purchase period of extended warranty but have not yet passed the standard quality warranty period. Customers shall bear different extended premium.
- During the extended warranty period, pv components GPRS, WIFI and lightning protection devices are not included in the extended warranty period. If they fail during the extended warranty period, customers need to purchase and replace them from the our company.
- Once the extended warranty service is purchased, our company will issue the extended warranty card to the customer to confirm the extended warranty period.

10.3. Invalid warranty clause

- Equipment failure caused by the following reasons is not covered by the warranty:
- 1)The "warranty card" has not been sent to the distributor or our company;
 - 2) Without the consent of our company to change equipment or replace parts;
 - 3) Use unqualified materials to support our company 's products, resulting in product failure
 - 4) Technicians of non-company modify or attempt to repair and erase the product serial number or silk screen;
 - 5) Incorrect installation, debugging and use methods;
 - 6) Failure to comply with safety regulations (certification standards, etc.);
 - 7) Damage caused by improper storage by dealers or end users;
 - 8) Fransportation damage (including scratches caused by internal packaging during transportation).Please claim directly from the transportation company or insurance company as soon as possible and obtain damage identification such as container/package unloading;
 - 9) Failure to follow the product user manual, installation manual and maintenance guidelines;
 - 10) Improper use or misuse of the device;
 - 11) Poor ventilation of the device;
 - 12) The product maintenance process does not follow relevant standards;
 - 13) Failure or damage caused by natural disasters or other force majeure (such as earthquake, lightning strike, fire, etc.).