




Vertical Coplanar Anodised

ACL-TS-D2-AMX Series (maximum width 1150mm)



Kit system

Coplanar structures (ACL/ACL-AMX) and inclined (AIR) vertical structures

With the modular kit system, it is possible to create any combination of rows of modules, regardless of their size. **Solitia structures are designed to support all conceivable possibilities**, bearing in mind that it is recommended to combine up to a maximum of 20 photovoltaic modules.


This system makes **the process of selecting and creating projects easier and faster**.

Module kits

All kits include profiles, profile joints, and omega and zeta fasteners for the panels.




Depending on the kit, surface fastenings can be L-shaped (coplanar^A) or with legs (vertically inclined^B).




Joining kits

Profile joint (x2) and universal omega brackets or clamps (x2).




Example of vertical coplanar structure for 7 modules (ACL04-TS-D2 + ACL03-TS-D2)


A 4-module kit + **B** Joining kit + **C** 3-module kit



Example of vertical sloping structure for 7 modules (AIR04-TS-D2 + AIR03-TS-D2)

A 4-module kit + **B** Joining kit + **C** 3-module kit






Vertical coplanar anodised

ACL01-TS-D2-AMX


DESCRIPTION	A Roof anchorage	B Profile 2380 mm	C Profile 1250 mm	D Side cover	E Profile joining	F AMX fastening	G Earthing connector
REFERENCE	STR034	-	-	STR2300	STR012	TS-TZ01-AP-30-35-DMX	STR040
UNITS	4	0	2	4	0	4	1



Vertical coplanar anodised

ACL02-TS-D2-AMX

DESCRIPTION	A Roof anchorage	B Profile 2380 mm	C Profile 1250 mm	D Side cover	E Profile joining	F AMX fastening	G Earthing connector
REFERENCE	STR034	-	-	STR2300	STR012	TS-TZ01-AP-30-35-DMX	STR040
UNITS	4	2	0	4	0	6	1



Vertical coplanar anodised

ACLo4-TS-D2-AMX

DESCRIPTION	A Roof anchorage	B Profile 2380 mm	C Profile 1250 mm	D Side cover	E Profile joining	F AMX fastening	G Earthing connector
REFERENCE	STR034	-	-	STR2300	STR012	TS-TZ01-AP-30-35-DMX	STR040
UNITS	8	4	0	4	2	10	1

Vertical coplanar anodised + Joining kits



Anchor distribution: 345mm ◀ 1470mm (x2) ▶ 345mm

ACLO3-TS-D2-AMX — Includes ACL01-TS-D2-AMX (1unit), ACL02-TS-D2-AMX (1unit) y ACL-KU-TS-D2-AMX (1unit)

DESCRIPTION	A Roof anchorage	B Profile 2380 mm	C Profile 1250 mm	D Side cover	E Profile joining	F AMX fastening	G Earthing connector
REFERENCE	STR034	-	-	STR2300	STR012	TS-TZ01-AP-30-35-DMX	STR040
UNITS	8	2	2	8	2	10	2



Anchor distribution: 225mm ◀ 1390mm (x4) ▶ 225mm

ACLO5-TS-D2-AMX — Includes ACL01-TS-D2-AMX (1unit), ACL04-TS-D2-AMX (1unit) y ACL-KU-TS-D2-AMX (1unit)

DESCRIPTION	A Roof anchorage	B Profile 2380 mm	C Profile 1250 mm	D Side cover	E Profile joining	F AMX fastening	G Earthing connector
REFERENCE	STR034	-	-	STR2300	STR012	TS-TZ01-AP-30-35-DMX	STR040
UNITS	12	4	2	8	4	14	2



Anchor distribution: 195mm ◀ 1350mm (x5) ▶ 195mm

ACLO6-TS-D2-AMX — Includes ACL02-TS-D2-AMX (1unit), ACL04-TS-D2-AMX (1ud.) y ACL-KU-TS-D2-AMX (1unit)


DESCRIPTION	A Roof anchorage	B Profile 2380 mm	C Profile 1250 mm	D Side cover	E Profile joining	F AMX fastening	G Earthing connector
REFERENCE	STR034	-	-	STR2300	STR012	TS-TZ01-AP-30-35-DMX	STR040
UNITS	12	6	0	8	4	16	2

Assembly instructions

Coplanar (ACL/ACL-AMX) and inclined (AIR) structures TS-D2 range in vertical position with panels up to 1150 mm



The profiles are placed vertically, with the narrow side where the omegas and zetas are located at the top, and the wider side on the side where the profile joints are placed.




STEP 01


Surface-mounted profile fasteners.

Assemble **L-shaped** anchors to profiles (TS-D2) for coplanar structures..

L-shaped anchor (STR087)




L-shaped anchor (STR034)



STEP 02

Profile layout

E.g.: For 6 panels, arrange **3 front profiles** and **3 rear profiles** measuring **2380mm**.



STEP 03


Profile joining

Join profiles together using the appropriate profile joints..

Vista frontal






Vista lateral



STEP 04

Fixing panels with universal clamps

Fix panels to profiles using the appropriate number of universal clamps, depending on the frame height. When used as an end/Z-clamp, it should be positioned at the end of the solar panel assembly; when used as a central/Omega-clamp, it should be positioned between the panels.
















ANCHOR DISTRIBUTION

Depending on the number of panels to be installed, the distance between front anchors, and consequently rear anchors, varies.

It is recommended and established that the safety distance from the end of the profile for profiles of 2390 mm, 2380 mm, 1250 mm, and 1192 mm should be 100–400 mm. Below is an example showing the horizontal distances between L-shaped anchors for 1 to 6 panels.

N° PANELES	1	2	3	4	5	6
Profiles 2390mm	-	2	2	4	4	6
Profiles 1192mm	2	-	2	-	2	-
Profiles 2380mm	-	2	2	4	4	6
Profiles 1250mm	2	-	2	-	2	-
Horizontal distance (mm)	1000~1600					
Safety distance (mm)	100~400					










No. of panels	Distances for ACL-TS-D2-AMX series profiles
 X1	 125 ‹ 1000 ‹ 125
 X2	 390 ‹ 1600 ‹ 390
 X3	 345 ‹ 1470 ‹ 1470 ‹ 345
 X4	 235 ‹ 1430 ‹ 1430 ‹ 1430 ‹ 235
 X5	 225 ‹ 1390 ‹ 1390 ‹ 1390 ‹ 1390 ‹ 225
 X6	 195 ‹ 1350 ‹ 1350 ‹ 1350 ‹ 1350 ‹ 1350 ‹ 195

Dimensioning of structures

Coplanar (ACL/ACL-AMX) and inclined (AIR) structures TS-D2 vertical range

When sizing a vertical structure, whether coplanar or inclined, we will follow some simple guidelines to calculate the material we will need to use.

We can classify the components of photovoltaic structures as follows:

	Profiles Panel support profile; the series determines the rest of the compatible elements and accessories.
	Profile joints They allow profiles to be joined together to extend them.
	Central pressers Also called omegas, they join the panels centrally.
	End pressers Also known as side pressers or zetas, they finish each row of panels by securing the ends.
	Universal pressers By adjusting their position with a 90° turn, they are suitable for use as central and end pressers.
	Surface mountings for coplanar Also known as eles, they allow you to attach to surfaces.
	Surface mountings for inclined They consist of front and rear legs, and attach to the surface while providing inclination.




The TS-D2 series profiles use the D fastening system, consisting of an Allen screw and D-type nut that allows for a perfect fit to the profile tabs. Therefore, all components used must be compatible to allow the use of this nut.

STEP 01

The first thing we need to know before starting to calculate our vertical structure is what size solar panels we want to install, both in terms of length and width as well as frame thickness; and the measurements of the components that make it up. This will tell us the length of the set of profiles we need for it.

Every structure will consist of an upper and lower support row, and the number of profiles to be used will always be even.

What measurements are needed to calculate the structure?



Length, width and thickness Pressure measurements

STEP 02


Once we know this, the next question we must ask ourselves is:

How many panels do we want to install on our structure?

Calculating the width of all of them together with the space occupied by the central and end pressers we use and the established safety measure will enable us to determine the number and size of the profiles we need and the total length of the top and bottom rows, which will always have the same measurements as they are identical.

How many panels are we going to install?

Example: Let us imagine that we want to place 4 panels along our structure and that these measure 2102 x 1040 x 35mm. Let us multiply their width by the total number of panels.




STEP 03

Once the previous step has been completed, we need to know how many central, end or universal clamps per row we need to use and how much space they will occupy.

The number of central clamps per row of profiles will always be the total number of panels available minus one. The number of end clamps per row will always be two. If using universal clamps, we must add the central clamps (the total number of panels minus one) and the two end clamps.

How many central and side pressers do we need?

Example: For 4 panels, we will need 3 central clamps and 2 end clamps, or 5 universal clamps per row, which we will multiply by 2, as a structure consists of a lower and upper row.




Let us now examine the space occupied by these pressers along the length of the row.

The internal size of the central clamps (TS-T01) is **25mm** between panels.
 The size of the end pressers (TS-Z01) will be **21mm** (panels with a 35 mm frame) or **26mm** (panels with a 30mm frame) at the end of each row of panels.
 The size of the universal pressers is **28mm** as omega and **34mm** as zeta.

How much space do our presses take up?


Example: The space per row for the three central clamps and two end clamps for four panels will be given by the sum of all of them. It should be noted that for panels with a thickness of 30mm, the end clamp will measure 26mm⁽¹⁾, and for panels with a thickness of 35mm, it will occupy 21mm⁽²⁾. If universal pressers are chosen, the thickness of the panel (30–35mm) does not affect the space, but it does change depending on the profile: 34 mm⁽⁴⁾ for zeta (Z) and 28mm⁽³⁾ for omega (T).



We must leave a **safety margin** of **10 mm** on each side of the rows of our structure to prevent assembly problems.

STEP 04

Once we have the total measurements of the set of panels and components that will be arranged in our structure, the next step is to choose the size of the TS-D2 profiles we want to use. The profiles are sold in various sizes:




To achieve the required size obtained after completing the previous steps, remember that we must take into account the number of panels, central, end or universal pressers and the safety measure; we simply need to combine the different profiles according to the parameters we consider appropriate.

Which profiles should you choose?

Example: If we add $4160+75+42+20$, the result will be 4297mm . Therefore, each of our rows with their profiles will have to measure at least that amount.

To save material, assembly time, or transport time, it is best to study the most suitable combination for the characteristics of each project.




STEP 05

Connections between profiles are necessary to keep them together in the same row, while also reducing the number of surface fixings required. The quantity to be chosen will depend on the number of profiles selected for the structure and will always be obtained by subtracting two from the total number of profiles.

How many profile joints do we need?

Example: If we have decided to use two 1192mm profiles and two 3588mm profiles for our four-panel structure, the number of joints required will be two ($4\text{ profiles} - 2 = 2\text{ units}$), one for the top row and one for the bottom row.



STEP 06

The final step in dimensioning the structure is to calculate the number of surface fixings required, the total quantity of which is determined by the spacing between the profiles along the row. We recommend a distance of between **1000mm**, which provides excellent fixation, and **1600mm** for coplanar structures, and **1400mm** for inclined structures.



The surface fastening must always be at a **maximum distance of between 100 and 500mm from the ends of the profile.**

How many surface fixings will we need??


Example: Given that the sum of the profiles is 4780mm and we must respect a distance from the end of the profile of between 100 and 400mm on each side, we see that if we wanted to place only three surface fixings per row, the distance between legs, 2090mm , would not be adequate. Let us look at the following calculation:

$$\times \quad 4780 - (300 \times 2) / 2 = 2090\text{mm}$$

In this case, it is divided between two, bearing in mind that we would have three surface fixings per row.

$$\checkmark \quad 4780 - (300 \times 2) / 3 = 1393\text{mm}$$


Having four surface fixings per row would be the optimal option.



*For our 4-panel structure, given that we will always have even rows,
we need a total of 8 surface fixings, 4 for the top row and 4 for the bottom row.*

STEP 07

The final step, once the distances between the rows of our structure have been established, is to determine the **vertical** distance at which the fixings should be placed on the surface. This will be determined by the distance between the profile fastenings to the panel and the angle of inclination, if any. These will be given by the range of distances and pressure points defined by the manufacturer, as well as those necessary to achieve the desired angle of inclination.



General safety information

To increase safety during the installation process and ensure greater stability of the PV modules, please read these recommendations and information carefully.

Before installation:

- + Upon arrival of the material, check that you have the correct quantities of each item.
- + Check that the installation site is suitable. Ensure that the ceilings are clean and dry, and that they are flat and free of irregularities.
- + The installation and handling of structural elements must be carried out by qualified personnel.

During installation:

- + Equip yourself with the appropriate equipment and follow safety regulations and occupational risk prevention guidelines to avoid accidents.
- + Follow general lightning protection advice. It is advisable to consult a specialist and check the weather before installation.
- + It is advisable to carry out the assembly with at least two people for greater safety in case of emergency.
- + Consult the photovoltaic module manufacturer's instructions regarding the assembly of solar panels on structures.
- + Leave a distance of at least 500 mm between the edges of the roof or other objects and the installation.
- + It is recommended not to install more than 20 panels in a continuous row. A small gap between adjacent rows will prevent expansion problems.





v.04-260506 ©SOLITIA 2026

The information contained in this catalogue is for informational purposes only and may be subject to change without prior notice.